

# INSTRUCTIONS FOR STABLE-LOCK

1. Install "Female" side in the stabilizer insert on the bow with 5/16" x 24 flathead screw. Make sure to install it very tight and that the "Female" housing is mounted on the bow with the OPENING TO THE SIDE.
2. Remove Jam Nut off of your stabilizer (if present).
3. Install "Male" side on the stabilizer stud. Do not put the male side on tight.
4. Now you can attach the stabilizer to your bow by inserting the male side into the female side and tighten it down by turning the stabilizer clockwise.

**CAUTION: DO NOT OVER-TIGHTEN STABILIZER, SNUG IS SUFFICIENT.**

5. To remove the stabilizer, rotate the stabilizer 1/2 turn counterclockwise and slip it out. The Stable-Lock can be used on most stabilizers, bow fishing reel seats and flash lights.

