

- 1. To ensure maximum adhesion, clean your hands free of contaminants that may adversely affect adhesion.
- 2. Clean your arrow shaft with Max Wipes.
- 3. Remove wrap from backing. Place adhesive side up on semi-soft surface (mouse pad).
- 4. Align shaft with edge of wrap and gently roll with mild downward pressure. Once wrap is applied, complete full adhesion by firmly rolling arrow on soft pad or rolling in your hands.
- 5. Clean wrap with a Max Wipe.
- 6. Index a vane over the wrap seam to help secure the warp.

Arizona Archery Enterprises

2781 N. Valley View Drive • Prescott Valley, AZ 86314 Phone: 928-772-9887 • Fax: 928-772-6287 www.arizonaarchery.com