



AAE EPOXY

Directions for Gluing Nock and Point Inserts

Installation of Nock Inserts

1. Clean inside of shaft with isopropyl alcohol (rubbing).
2. Mix AAE Epoxy thoroughly. With a match stick or toothpick, wipe a bead of adhesive on the inside of the shaft. Push the insert into the shaft 1/8". Wipe a very thin film of adhesive on the outside of the insert.
3. **THIS IS IMPORTANT:** While rotating the insert, push the insert in the shaft until it bottoms out on the shoulder.
4. Wipe off excessive adhesive. Set the arrow on the insert until completely cured (24 hours).

Installation of Point Inserts

The point insert is installed with the same procedure as the nock insert, with one exception. Make sure the shaft is cut to proper length before installing the insert.

CAUTION! EYE AND SKIN IRRITANT. CONTAINS EPOXY RESIN AND POLYAMINE HARDENER. IN CASE OF SKIN CONTACT, WIPE OFF CONTAMINATION AND WASH THOROUGHLY WITH SOAP AND WATER. IN CASE OF EYE CONTACT, FLUSH WITH WATER FOR 15 MINUTES AND GET PROMPT MEDICAL ATTENTION. IF SWALLOWED, GET IMMEDIATE MEDICAL ATTENTION. USE WITH ADEQUATE VENTILATION. KEEP OUT OF REACH OF CHILDREN.

Look for All of AAE's Quality Archery Products

- Max Hunter Vanes
- Plastifletch Max Vanes
- Elite Plastifletch Vanes
- Max Bond Glue • Fastset Gel
- Max Arrow Cleaner
- Fletch III Cross Bolt Adapter
- Plastinock

ArizonaArchery.com • 928-772-9887

2781 N. Valley View Drive • Prescott Valley AZ 86314

WEAR SAFETY GLASSES WHEN USING THIS PRODUCT